

TIPS TO CONSERVE ENERGY IN YOUR HOME

- Turn off unnecessary lights.
- Use LED bulbs.
- Close your blinds/curtains to keep out afternoon heat.
- Save up to 50% on outdoor lighting by installing motion sensor lights.
- Install and set a programmable thermostat.
- Set water heater temperature to 120 degrees.
- Only run full loads when using large appliances (washer, dryer, dishwasher).
- Wash clothes with cold water.
- Air dry dishes instead of using dishwasher.
- Use microwave when you can instead of electric oven.
- Use appliances in off-peak hours when you can, usually after 7pm.
- Take shorter showers.
- Turn off computers, TV's and other electrical items when not in use. Don't leave them on standby.
- Unplug items you are not using.
- Seal and caulk your leaky windows and doors and replace worn weather stripping. Keep windows and doors tightly shut when running AC or heater.
- Replace air filters regularly